

Making the Most of Your StorCenter: Using USB Storage

Your StorCenter server allows you to connect FAT, FAT32, and NTFS formatted device to expand your on-line storage.

Introduction	2
Connecting External Storage	2
Safely removing external storage	2
USB storage device not recognized	2



Introduction


Your StorCenter server allows you to connect FAT, FAT32, and NTFS formatted devices to expand your on-line storage.

Connecting External Storage

The External Storage page displays a list of externally connected storage devices. To access the External Storage page, navigate to the Settings tab and click **External Storage**. You can connect a USB storage device to your Iomega StorCenter using one of the provided USB ports. When you connect external storage to your Iomega StorCenter device, that device content is accessible from the **Shared Folders** tab.

The StorCenter will support a storage device on each available USB port. Iomega does NOT support USB hubs.

Safely removing external storage

Click  to safely remove the external storage. A confirmation dialog will display. Click **OK** to remove the external storage. When the external storage has been removed from the **External Storage** table, it is safe to remove and you may unplug it from the Iomega StorCenter device. When the external storage is safely removed, its associated Shared Folder is removed as well.

USB storage device not recognized

If your storage device does not appear as an available shared folder, try the following guidelines.

1. If the USB device requires power, make sure it is plugged into an electrical outlet or UPS and that the power is ON.
2. Make sure the USB storage device is connected to a USB port on the StorCenter. Iomega does NOT support USB hubs.
3. The StorCenter should automatically share a storage device on each available USB port.
4. Make sure the USB Storage Device has a FAT, FAT32, or NTFS (Windows) format.
5. The StorCenter will not recognize removable devices such as optical (CD, DVD, and Blu-ray) or Iomega REV drives.



Copyright © 2009 Iomega Corporation. All rights reserved. Iomega, StorCenter, and the stylized "i" logo are registered trademarks of Iomega Corporation in the United States and/or other countries. EMC and Retrospect are registered trademarks of EMC Corporation in the United States and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple, Macintosh, and Mac are either registered trademarks or trademarks of Apple Inc. in the United States and/or other countries. Certain other product names, brand names, and company names may be trademarks or designations of their respective owners. 032009a