

## Making the Most of Your Iomega® ScreenPlay™ Pro Multimedia Drive

# Setting Up Your ScreenPlay Pro HD in a Wireless Network

Take advantage of the WiFi-ready capability of your ScreenPlay Pro HD!



|                                 |   |
|---------------------------------|---|
| Getting Started                 | 2 |
| Physical Installation           | 2 |
| Wireless Setup                  | 3 |
| Re-connecting to the Network    | 3 |
| Viewing Files from the Network  | 4 |
| Copying Files to the ScreenPlay | 4 |
| Troubleshooting Tips            | 5 |



## Getting Started

The Iomega ScreenPlay Pro HD is fully WiFi-ready – to connect it to your wireless network, all you need is to plug in a supported WiFi adapter and complete the wireless setup. The ScreenPlay Pro HD package does not include a WiFi adapter, so you'll need to obtain one. You can purchase an accessory wireless adapter from [www.iomega.com](http://www.iomega.com) (pictured to the right), or check the support area for a list of supported WiFi adapters.



**NOTE:** You must have a wireless network in place for this setup. If you do not already have a wireless network installed, you will need to obtain a wireless router and install it before you can set up a wireless connection for the ScreenPlay Pro HD.

## Physical Installation

1. Connect the WiFi adapter to the USB host port on the back of the ScreenPlay Pro HD drive.
2. If you haven't already done so, connect the ScreenPlay Pro HD to your TV set. If you need detailed instructions, see "Installing Your ScreenPlay Pro HD" in this series or refer to the ScreenPlay Pro HD User's Manual.
3. Connect the power supply to the ScreenPlay Pro HD and an uninterruptible power supply (UPS) or power outlet.
4. Now you're ready to complete the wireless setup. Follow the instructions on the next page.



## Setting Up the Wireless Connection

1. Press the Standby/Power button on the front of the ScreenPlay Pro HD to turn it on, or press the **STANDBY** key on the ScreenPlay Pro HD remote control
2. From the main ScreenPlay menu, select **Setup** and press the **ENTER** key on the ScreenPlay Pro HD remote control.
3. Select **Network** and press the **ENTER** key.
4. Select **Wireless Setup** and press the **ENTER** key.
5. Select **Modify** and press the **ENTER** key.
6. Select your network from the list of available wireless networks and press the **ENTER** key.



**NOTE:** If you need to enter a username and password to login to a network volume, use the virtual keyboard on the ScreenPlay Pro HD TV display. The password can use any combination of numbers and letters (lower case or caps). It can also use periods. It cannot use extended punctuation characters (such as !, @, #, \$, %, &, etc.)

7. When the configuration is complete, the ScreenPlay Pro HD will automatically connect to the wireless network. If it connects successfully, you will see a message indicating "Test complete", and the Network Setup menu will display showing the IP address used by the ScreenPlay Pro HD.
8. Press the **HOME** key to return to the ScreenPlay Pro HD main menu.

Now you're ready to start enjoying wireless access to all the multimedia content on your network. See the instructions on page 4.

## Reconnecting to the Wireless Network

Follow these instructions if the ScreenPlay Pro HD loses connection to the network.

1. From the main ScreenPlay menu, select **Setup** → **Network** → **Wireless Setup**.
2. Select **Connect** and press the **ENTER** key on the remote control.

The ScreenPlay Pro HD will automatically re-connect to the wireless network and display the IP address.

## Playing Multimedia Files from the Network

Once you have set up a wireless network connection to your ScreenPlay Pro HD, it's easy to stream your videos, music, and photos directly to your TV from any volume on your wireless network.

1. From the main ScreenPlay menu, select **Network** and press the **ENTER** key on the remote control.
2. The Network menu will show volumes available on your network. Use the cursor keys on the remote control or front of the ScreenPlay Pro HD to browse to and select the media files you want to play.

**NOTE:** If you need to enter a username and password to login to a network volume, press the ENTER key on the remote control to bring up the ScreenPlay virtual keyboard. Use the remote control and the ENTER key to select the necessary characters.

3. Once you have highlighted the file you want to play, press the **ENTER** key. For information on using the remote control while playing media files, refer to the ScreenPlay Pro HD User's Manual.

## Copying Multimedia Files to the ScreenPlay Pro HD

Use these instructions if you want to transfer media files from a network volume to your ScreenPlay Pro HD.

1. Run ScreenPlay Discovery to automatically connect to the ScreenPlay Pro HD from a Windows PC on the network:
  - a. Insert the Solutions CD that shipped with the ScreenPlay Pro HD and install the ScreenPlay Discovery utility.
  - b. Click **Start** → **Iomega** → **ScreenPlay Pro HD**.
  - c. Double click the icon for **ScreenPlay Discovery**.

**NOTE:** You can also connect to the ScreenPlay Pro HD from a Mac, but you will need to reformat the ScreenPlay hard drive in order to write files to it from Mac OS. See the user's manual for more information.

2. Open My Computer or Windows Explorer and locate the drive letter assigned to the ScreenPlay Pro HD.
3. Use the standard methods for your operating system to create folders on the ScreenPlay Pro HD and copy-and-paste or drag-and-drop your files.



## Troubleshooting Tips

Try these suggestions if the ScreenPlay Pro HD is not recognized on the network.

- Make sure the ScreenPlay Pro HD is connected to power and turned on. The blue LED glows when the ScreenPlay Pro HD is powered up. If the LED is off, press the Standby button on the front of the ScreenPlay Pro HD to turn it on. The blue power/access LED will blink while the ScreenPlay Pro HD powers up, then glow steadily.
- Make sure you are using a supported WiFi adapter. Check the Support area on **www.iomega.com** for the latest information on supported WiFi adapters.
- Make sure the WiFi adapter is securely connected to the USB host port on the back of the ScreenPlay Pro HD drive. You should see a message on the ScreenPlay Pro HD TV display indicating Wifi plug-in.
- Make sure you have set up the wireless access point for the ScreenPlay Pro HD. Refer to the instructions on page 3.
- Wait a few minutes and then try connecting to the ScreenPlay Pro HD again.
- Try rebooting your computer and connecting to the ScreenPlay Pro HD again.
- Make sure the computer you are using to connect to the ScreenPlay Pro HD is on the same subnet or network segment as the ScreenPlay Pro HD.



Copyright © 2009 Iomega Corporation. All rights reserved. Iomega, ScreenPlay, and the stylized “i” logo are registered trademarks of Iomega Corporation in the United States and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple and Mac are either registered trademarks or trademarks of Apple Inc. in the United States and/or other countries. Certain other product names, brand names, and company names may be trademarks or designations of their respective owners. 031209b